

Safety information and warnings – Electric hob

(safety information and warnings within the meaning of Article 19 D)

REGULATION (EU) 2023/988 OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL
of 10 May 2023

on general product safety, amending Regulation (EU) No 1025/2012 of the European Parliament and of the Council and Directive (EU) 2020/1828 of the European Parliament and the Council, and repealing Directive 2001/95/EC of the European Parliament and of the Council and Council Directive 87/357/EEC

SAFETY INSTRUCTIONS

Warning: The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements. Children less than 8 years of age shall be kept away unless continuously supervised.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Warning: Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.

NEVER try to extinguish a fire with water, but switch off the appliance and then cover flame e.g. with a lid or a fire blanket.

Warning: Danger of fire: do not store items on the cooking surfaces.

The appliance is not intended to be operated by means of an external timer or separate remote-control system.

You should not use steam cleaning devices to clean the appliance.

Ensure that children do not play with the appliance.

Make sure that the power cords of other equipment do not touch any hot surfaces of the appliance.

Plug of the power cord must be accessible after appliance has been installed.

Do not install the appliance near the cooling equipment.

Do not leave the appliance unattended while cooking. Oil and fats may ignite due to overheating.

In the event the appliance is damaged, do not use it until it is repaired.

Persons without proper qualifications and training must not make any alterations or repairs of the appliance.

In case of any technical defect, immediately unplug or disconnect the appliance (as explained above) and refer the defect to service to be repaired.

Using the appliance for cooking and baking results in the emission of heat and moisture in the room in which it is installed. Make sure that kitchen is well ventilated. Natural ventilation openings or forced mechanical ventilation (exhaust hood) should be available.

Prolonged intensive use of the appliance may require additional ventilation, for example, opening a window or a more effective ventilation, such as increasing efficiency of mechanical ventilation, if applicable.